



Arts & M bldg. AV Controls

Power button to turn on/off the LCD projector. LCD projector **input display**.



VCR/VHS power button. **Computer** power button



Audio power button. **Master volume knob**. Individual volume knobs (PC, VHS/VCR, etc.)