

## DIRECTIONS FOR MEDIA PRESENTATION STATION

### COMPUTER

Power ON computer (press power button on computer)

Monitor should power ON with computer, if not press power button (front of monitor)\*

\*Note: no picture on monitor? Check the switch box on front of desk

#1 input = computer, #2 input = portable computer\* (green light on #1 should be selected)

Press Ctrl-Alt-Delete and then log onto the student network

Log on Name: evcfaculty

Password: presentation

Log on to: evcstu

Adjust computer sound using wall panel knob located next to desk

\*Portable computer (laptop) can be connected using wall VGA connection

User must supply VGA & network cable. Use red network jack located on wall next to computer station. Switch input to #2 (Laptop)

### DATA PROJECTOR (to project computer image or videotape image)

Use Remote Control (stored in lock box, need key #838 – see your Dean for key request)

Press “Power On” button (point remote at projector or bounce beam off screen)

Green lamp will flash while projector is warming up & steady green when ready

Select Input: Input 1 = Computer

Input 3 = VCR

To POWER OFF press “Power Off” button and press **again** while message is displayed  
Power indicator will be Red and cooling fan will run until projector lamp has cooled!

### VIDEO PLAYER

Power ON player (newer models will automatically power on when tape is inserted)

Insert tape & play

Power ON data projector (use remote for data projector)

Set input on data projector to #3 for video signal

Adjust volume using audio wall panel knob (located on wall next to computer station)

### SHUT DOWN

When finished, power off all equipment.

To power off data projector, press the OFF button **twice**. Red light indicates off mode.

Return REMOTE CONTROL to box and **lock** the box.